


```
1
                  Literature Parts
      LIT3397618 Instructions, Installation
      LIT8528324 Use & Care Guide
      LIT3406692 Label, Wiring Diagram
Following May Be Purchased DO-IT-YOURSELF REPAIR MANUALS
      LIT677818
                 Dryer
2
                  Screw, 10-16 \times 1/2
      343641
3
      693995
                  Screw, 8-18 \times 3/8
                  Cover, Block
5
      3396795
6
      342043
                  Screw, 10-32 \times 3/8
7
      3396805
                  Panel, Rear
10
     3406107
                  Door Switch Assembly
11
     697773
                  Screw, 6-20 \times 7/8
                  Screw, 10-16 \times 1/2
13
      3357011
14
                  Spring, Door (2)
      692495
15
      3394083
                  Clip, Front Panel (2)
16
      3392100
                  Foot, Dryer
      279810
                  Foot-Optional (Extended Length Package of 2) (Not Included)
17
      279318
                  Terminal, Tinned & Brass (3) (Includes Illus. 39)
                  Cabinet
18
      3399585
                  White
                  Biscuit (Includes Illus. Nos. 5, 7, 15, 41 And 45.)
      3399595
19
      98234
                  Clip, Ground
                  Lock, Front Top (2)
2.0
      690363
21
                  Panel, Front
      695620
                  White
      3977244
                  Biscuit
23
                  Clip, Felt Pad (3)
      685203
24
      3389441
                  Catch, Door Assembly
26
      337189
                  Clip, Hinge (2)
27
                  Screw, 8-18 \times 3/8
      694091
      8066056
                  Hinge, R.H.
28
      8066057
                  Hinge, L.H.
                  Strike, Door
33
      696144
                  Door, Rear
35
      695737
36
                  Door, Front
      3393549
                  White
      3977241
                  Biscuit
37
                  Handle, Door
      690270
                  White
      3977242
                  Biscuit
38
      3406129
                  Seal & Bearing Assembly
39
      279393
                  Terminal Block Kit (For Terminal Block)
                  Screw, 10-32 \times 5/8
40
      697776
                  Block, Terminal
41
      3397659
                  Hinge, Top (2)
42
      238088
43
      3394332
                  Idler & Slide Assembly
                  Belt, Drive
44
      8066065
                  Base, Motor
45
      348780
      3400500
                  Bolt, 5/16-18 \times 3/4
46
47
      3394341
                  Pulley, 60 Hz.
48
      661654
                  Motor Assembly 60 Hz.
49
     660658
                  Clamp, Motor
5.0
      3404162
                  Clamp, Motor (W/Shield)
51
      3390731
                  Seal, Door
52
      3393008
                  Screw, 10-16 \times 1/2
```

## **TOP AND CONSOLE PARTS**

For Models: LER7620KQ0, LER7620KT0 (Designer White) (Biscuit)



4377918 3

```
Panel, Rear Console
1
     8274261
                  Wire, Jumper (Black)
2
      3401684
                  Screw, Hex Head
3
      693995
4
                  Cap, End (L.H.)
     8271365
                  White
     8271368
                 Biscuit
5
     3405156
                  Switch, Finish Guard
6
     388326
                  Screw, Console
                  Buzzer, Mini
7
      694419
8
                  Cap, End (R.H.)
      8271359
                  White
      8271362
                 Biscuit
9
      3399639
                  Switch, Temperature
10
      349639
                  Screen, Lint
11
                  Cover, Lint Screen
      8283378
                  White
      8283380
                 Biscuit
12
     3978605
                 Hinge, R.H.
                 Hinge, L.H.
     3978606
13
     688983
                  Screw, 8-18 \times 5/8
14
     3400859
                  Screw, Grounding
15
     3395683
                  Connector (Motor)
16
                  Top
      8271390
                  White
      8271392
                  Biscuit
17
                  Knob, Control (3)
      8271339
                  White
     8271348
                 Biscuit
     3394427
                 Clip-Harness
18
19
     297535
                  Bumper, Lint Lid
20
      3401144
                  Connector, (PTS Relay)
21
     8299766
                  Timer, 60 Hz.
22
     3397695
                  Wire, Jumper (Guard On/Off)
23
     3396029
                  Wire, Jumper (Temperature)
24
     3401075
                  Resistor Assembly
29
     3390646
                  Screw, Mounting (8-18 \times 5/16)
                  Nut, Push-In (2)
30
      357213
31
     3394306
                  Harness, Wiring
33
     3397269
                 Connector (Timer)
     3347243
                  Connector 6-Circuit
34
35
     94614
                  Terminal
39
      3398095
                  Switch, Push-To-Start
40
                  Timer Knob Assembly
      8312687
                  White
      8271404
                 Biscuit
41
      3936144
                 Connector
42
     8271418
                  Bracket, Control
43
                  Panel, Control
      3977861
                  White
      3977870
                 Biscuit
```

## ACCESSORY PARTS

3406839 Dry Rack 279948 Dryer Repair Kit

PAINT, TOUCH-UP (1/2oz.)

72017 White 4392899 Biscuit

PAINT, PRESSURIZED SPRAY (12 oz.)


350930 White 4392901 Biscuit 350938 Primer, Gray

PAINT, BULK (1 qt.)

799344 White (Uncut) 4392900 Biscuit (Uncut)

## **BULKHEAD PARTS**

For Models: LER7620KQ0, LER7620KT0 (Designer White) (Biscuit)



4377918 5

```
1
     348368
                 Lint Chute Assembly
                 Screw, 8-15 \times 1/2
2
     487909
                 Washer-Support
3
     3388703
     347139
                 Seal, Lint Chute
4
5
     90767
                 Screw, 8-18 \times 3/8
6
     696302
                  Shield, Exhaust
7
     3392519
                 Thermal Fuse
8
     3387134
                 Thermostat, Internal-Bias
     3977393
                 Thermal, Cut-Off (Hi-Limit Thermostat Illus. No.15 Included)
9
10
     694089
                 Wheel, Blower (Includes Illus. No. 22)
11
     3405016
                 Housing, Blower
12
     3398161
                 Clip
13
     343641
                  Screw, 10-16 \times 1/2
14
     3397566
                 Box, Heater
15
     3977767
                 Thermostat, 221~F (105~C)
                 Bracket, Drum Light
16
     3977373
17
     3403585
                 Element, Heater
18
     8066086
                 Drum Hole Plug
19
     279457
                 Wire Kit, Terminal (For Heater Element Wiring Harness Repair)
20
     489463
                 Screw, 8-18 \times 5/8
     3394196
                 Seal, Blower
22
     3406124
                 Bulb
33
                 Lens, Drum Light
34
     3402841
     690997
                 Ring, Tri
41
     3399506
                 Shaft, L.H.
42
43
     3399507
                  Shaft, R.H.
44
     3397588
                 Roller, Support
                  Washer, Support
46
     348197
47
     3359452
                 Nut, 3/8-16
                 Bulkhead
48
     3403413
49
     3403634
                  Socket Assembly
                 Ring, Bearing (2)
50
     692526
                 Screw, 11-16 x 3/4
51
     97787
52
     3406130
                  Seal, Rear Drum
53
     695587
                 Drum Assembly
                 Baffle, Drum (2)
54
     692490
                 Bracket, Support
55
     3976434
     90296
56
                 Clip
57
     3403636
                 Baffle, Drum (1)
     339956
58
                  Seal
```